

# Optimizing Mouse Control

In a typical keyboard-mouse control system, mouse is always used to control aiming and turning around. It is simple, but this is the core of FPS games.

And **mouse control** on game consoles will be affected by the following items:

## Step 1. Mouse Settings (DPI/CPI and USB report rate)

**Recommended DPI/CPI: 4000-16000.**

**5000 DPI will be a safe starting point.**

bigger DPI gives you faster turning speed,  
smaller one gives you more stable aiming.

**Recommended USB report rate: 250 - 1000**

**500HZ** will be acceptable for most of the situations.

For some mice, proper software or driver from the mouse manufacture will be in need to change DPI and USB report rate.

## Step 2. Game settings in console(PS/Xbox/SWITCH)

**The goal is to set the highest sensitivity for gamepad right stick to harness all the potential of your game, for our mouse movement is mapped to the right stick.**

**Please do put this in mind.**

There might be many settings in a game, which will show their effect on mouse control. Here are some recommendations:

**Sensitivity = MAX**

It is called by various names, such as Look Sensitivity, Aim Sensitivity or just Sensitivity.

It's recommended to set all sensitivities to MAX.

**Acceleration = MAX** (unless otherwise specified)

**Response Curve = Default** (unless otherwise specified)

**Dead zone = Default**

Our Engine is trained on this, so please keep it as default.

**Button Layout = Default**

It's better to leave **Button Layout** as defaults to avoid confusion.

**More recommendations for game settings can be found in our APP.**

Or in this video list:

[https://www.youtube.com/playlist?list=PL\\_W7SvvWDzBOqxdSxBsr11E7rg7czSpYV](https://www.youtube.com/playlist?list=PL_W7SvvWDzBOqxdSxBsr11E7rg7czSpYV)

### Step 3. ReaSnow S1 Settings

#### **HIP/ADS Sensitivity:**

When **mouse** and **game** have been set properly,  
if turning speed is acceptable in game, please choose smaller values for HIP  
and ADS sensitivities to have a fine aiming.

if turning speed is too slow, just add some to these 2 sensitivities.

Other settings such as **YX Ratio**, **MIN Speed**, **Curve** will also change the  
behavior of mouse control, leave them as default unless you know the effect.

#### **Activated Config:**

Every preset game config contains a special Engine which is trained and  
designed for this game, please DO use the corresponding config to play your  
game.

For games which are not in this preset list, please choose the most similar  
one.

#### **Scenarios:**

Scenarios can also be treated as sub configs, there are 5 scenarios in one  
config.

**HIP and ADS** are for infantry,

**TBD1/2/3** are for vehicles, such as tank, plane or for inventory and map  
control.

Each scenario has a sensitivity of its own, and when this scenario is  
activated by a hotkey, the corresponding sensitivity will take effect.

By default, HIP and its sensitivity will be effective.

And when the ADS/TBD1/TBD2/TBD3 is released, HIP will be resumed too  
automatically, so generally speaking, there is no need of a hotkey to activate HIP  
manually.


### **PS1. Advanced Settings – Curve Editor**

“Curve” here is used to represent the relationship between mouse speed and cursor speed on screen.

By default, a straight line will be provided by ReaSnow Intelligent Engine, which means there is a 1:1 relationship between mouse speed and cursor speed. But under certain circumstances, a non-straight-line relationship will be in need to boost velocity, accelerate, decelerate or set speed limits. These can not be fulfilled by changing the sensitivities directly.

PS. Please do not play around the Curve unless the above **3 Steps** are followed properly and the sensitivities of your mouse is acceptable.

Let's take a look at the defaults curve:



### Intelligent Engine Info:

Currently, it is HIP. This is a sub engine of IE3.0 used for HIP scenario.

Curves are used to change the behavior this sub engine,

Generally speaking, there is no need to change this parameter.

### Input Data from mouse(Mouse Speed)

This is the original speed ReaSnow S1 gets from a mouse when it is moving.

### Output Data(Cursor Speed)

This is the output after the original mouse speed have been processed and changed by the curve.

In the end, this output data will be used to control cursor movement on screen.

The blue **Raindrop icons** and the **Plus and Minus icons** can be used to change the curve.

A1: MIN mouse speed


A2: MAX mouse speed

B1: MIN cursor speed

B2: MAX cursor speed

### Some useful curves:

1. Vehicle control




This curve will be useful to get faster turning speed to control a vehicle, or some other circumstances where you need faster turning.

This curve means it will keep 1:1 nature while mouse speed is low and that makes aiming easy. And when mouse speed is fast, the cursor speed will be boosted. That will help you to get a faster turning speed, but you will have no 1:1 control when these dots are not on the straight line.


As shown in the above picture, the input(mouse speed) 110 has been boosted to 200(MAX cursor speed).

## 2. Fine aiming



This curve can be used in ADS scenario, when ADS is enabled(Holding mouse right button). You can get a fine and stable aiming. But the cursor speed will be lowered undoubtedly. As shown in the above picture, the input 90(mouse speed) has been lowered to 38(cursor speed).

### 3. Other curves



**PS2. Mouse Settings examples:**  
**Logitech**

### Pointer Settings

**DPI Sensitivity Levels** 1 Number of levels

5000 Assign Default Assign Shift

0

0

0

0

100 ..... 12000

**Report Rate**  
Choose a polling rate for your mouse (reports per second)

125  250  500  1000

Restore Defaults

## Razer

**SENSITIVITY**  
The number of dots-per-inch [DPI] of mouse movement.

ENABLE X-Y SENSITIVITY CONFIGURE SENSITIVITY STAGES

100 ..... 5600

**ACCELERATION**  
The rate of increase of speed in the cursor with respect to mouse movement.

0 1 2 3 4 5 6 7 8 9 10

**POLLING RATE**  
The frequency of data updates for the device.

1000

**Current DPI** 5600 Sensitivity Stages

100 1000 2000 3000 4000 5000 5600

Enable independent X-Y Sensitivity

Enable On-The-Fly Sensitivity On-Screen Display

**Acceleration**

1 2 3 4 5 6 7 8 9 10


Enable Acceleration

**Polling Rate** 125Hz 500Hz 1000Hz

## Corsair



**PS3. Game Setting Examples:**  
**Battlefield 4**




**Call of Duty: Ghost**



**GTA5**



## Destiny



## Kill zone: Shadow Fall



## Warframe






### PS4. Glossary:

**DPI:** Dots per inch (DPI) is a measurement of how sensitive a mouse is. The higher a mouse's DPI, the farther the cursor on your screen will move when you move the mouse. A mouse with a higher DPI can detect and react to smaller movements. While unstable signals might also be caused when some mouse is set to its MAX.

**CPI:** Counts Per Inch (CPI), In short, **CPI** and **DPI** essentially cover the same specification of a mouse and can be used interchangeably.

**HIP:** Shooting without aiming optics

**ADS:** Shooting with aiming optics



### YX Ratio:

It's the ratio of mouse's speed in Y and X directions.